

# Muster: Handytasche Pferd-Button

8.40x11.15 cm  
 9200 stiche.  
 11 wechsel.  
 Garn: 34.40 m

01-R:204,G:204,B:255	07-R:248,G:195,B:000
02-R:153,G:102,B:051	08-R:218,G:037,B:029
03-R:153,G:000,B:000	09-R:144,G:030,B:120
04-R:221,G:019,B:123	10-R:150,G:149,B:148
05-R:247,G:197,B:180	11-R:000,G:146,B:063
06-R:031,G:026,B:023	

Skalieren: 100%



## Muster sequenz information (Wechsel, Stops e.t.c):

01) N:11 (R:000,C	02) N:08 (R:218,C	03) N:01 (R:204,C	04) N:10 (R:150,C	05) N:04 (R:221,C	06) N:03 (R:153,C
07) N:02 (R:153,C	08) N:05 (R:247,C	09) N:03 (R:153,C	10) N:06 (R:031,C	11) N:09 (R:144,C	12) N:07 (R:248,C